



INSTRUCTION MANUAL

Nero Emergency Torch

Product number: 720011

INSTRUCTION & STATEMENT

- 1) Fix the torch holder onto the door or wall with screws.
- ② Unscrew the torch handle to insert 3 x AA carbon batteries into the battery holder. Ensure correct polarity.
- (3) Screw back the handle. The torch should light up.

IN CASE OF EMERGENCY

Remove the torch from the holder and it will switch on automatically. Place the torch back to the holder, it will switch off automatically.

Backed by Nero's 12 month replacement guarantee.

Nero is a registered trademark of

R. Weatherdon & Co Pty Ltd

Made in China

Email: sales@weatherdon.com.au Ph: +61 2 9906 2202 Visit: www.weatherdon.com.au

This item is subject to change due to model updates from time to time.