

**Storage:**

After using, pull out the plug, pour out the remaining water, turn the steam control to minimum, turn the temperature control to minimum, let the iron cool down and place the iron in a safe and dry place vertically.

**Attention:**

1. Please read the owner's manual before using the product.
2. Use distilled or boiled water only. Do not fill in with any other liquid except water.
3. The iron must not be left unattended while it is connected to the supply mains.
4. The plug must be removed from the socket-outlet before the water reservoir is filled with water.
5. When placing the iron on its heel, ensure that the surface on which the iron is placed is stable.
6. The iron must be used and rested on a stable surface.
7. The iron is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
8. Children should be supervised to ensure that they do not play with the appliance.

**Cautions:**


1. Make sure that the applied voltage is same as the rating voltage, and the socket has effective earth connection.
2. If the supply cord is damaged, it must be replaced by the manufacturer or a qualified person in order to avoid a hazard.
3. This iron is for household only.
4. Do not immerse the iron into any liquid for cleaning.
5. Do not touch any hot metal parts, hot water, or steam to avoid scalding.

**Main technical parameters:**

Type	Rated voltage	Rated frequency	Rated power
AJ-2048-22	220-240V	50/60Hz	2000-2400W

# Nero®

## NON-STICK, AUTO-OFF, STEAM/DRY IRON MODEL 450



Please read these instructions before use and view the illustration components before using the appliance.

---

Backed by Nero's 12 month replacement guarantee

Imported By Weatherdon


[www.weatherdon.com.au](http://www.weatherdon.com.au)

Made in China



## Components:

This product has many features such as a temperature regulating dial, spraying, dry ironing, variable steam, and steam burst. It also features an easy to grip shape, with high heat efficiency, resulting in quick ironing of clothes.



- |                               |                                 |
|-------------------------------|---------------------------------|
| A: Non-stick soleplate        | R: Top handle                   |
| B: Spray nozzle               | I: Rear cover                   |
| C: Handle                     | J: Pilot light temperature dial |
| D: Fill cover                 | K: Clean button                 |
| E: Steam on/off switch        | L: Water tank                   |
| F: Spray & burst steam button | M: Skirt adornment              |
| G: Heating indicator light    | N: Skirting base                |
| H: Cord guard                 |                                 |

## Filling water:

1. Before filling water, please pull out the plug first.
2. Set the steam control to the minimum position.
3. Pull open the cover of water filling mouth, then fill water.

## Spraying:

Press the spraying button, steam will spray out from the spraying nozzle. Enough water should be kept in the water tank for steaming.

## Steam ironing:

1. To use steam ironing, turn the steam on/off switch to the minimum position and set the temperature control on the dial to the max position.
2. After the heating indicator light goes out, turn the steam on/off switch to maximum position, steam can be sprayed and ironing can start.

## Bursting steam:

Set the temperature control dial to the maximum position, then press down the bursting steam button, the base plate will spray out bursting steam.

## Dry ironing:

Turn the steam on/off switch to the minimum position, set the temperature control to the suitable position, you can start dry ironing.

## Self cleaning:

First fill the tank with water, then turn the iron on and set the temperature control to the maximum position, after about 3 minutes press the self-clean button for about 1 minute, strong steam and hot water will be sprayed to clean the steam chamber. Use this function once every two weeks if the iron has been used regularly.

## Automatic shut off:

If the iron is switched on and not moved for a period of 8 minutes while standing on its heel or 30 seconds while resting on the soleplate, an internal safety feature will switch the iron off and the auto-shutoff indicator will blink. Move the iron to turn on heating again.