

Storage:

After using, pull out the plug and pour out the remaining water. Turn the steam and the temperature control to “min”. Let the iron cool down, then store the iron vertically in a safe and dry place.

Attentions:

1. Please read the owner’s manual before using the product.
2. Do not fill iron with any other liquid except water.
3. The iron must not be left unattended while it is connected to the supply mains.
4. The plug must be removed from the socket outlet before the water reservoir is filled with water.
5. The iron must be used and rested on a flat, stable surface
6. The iron is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking.
7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
8. Children should be supervised to ensure that they do not play with the appliance.
9. When placing the iron on its stand, ensure that the surface on which the stand is placed is stable
10. If the supply cord is damaged, it must be replaced by the manufacturer, service agent or qualified persons in order to avoid a hazard.
11. Surfaces are liable to get hot during use.

Cautions:


1. Make sure that the applied voltage is the same as the rating voltage.
2. This iron is for household use only.
3. Do not immerse the iron into any liquid for cleaning.
4. Do not touch the hot metal plate, hot water, or steam to avoid scalding.

Nero®

Nero 800 Steam/Dry Iron

PRODUCT CODE:

742815 - Nero 800 Ceramic




Please read these instructions for use and have a good look at the illustration before using the appliance

Main technical parameters:

Type	Rated voltage	Rated frequency	Rated power
742815	220-240V	50Hz	2000-2400W

Characteristics and structure:



A: Soleplate

B: Skirt

C: Handle

D: Back Cover

E: Spray ASM

F: Top cover

G: Fill cover

H: Steam knob

I: Spray & Burst steam button

J: Auto off light

K: Cord guard

L: Pilot light

M: Temperature dial

N: Water tank

O: Clean button

Filling water:

Spraying:

Press the spraying button, and water will spray out from the spraying nozzle. Always keep enough water in the water tank.

Steam ironing:

1. To use steam ironing, turn the steam control to minimum position and set the temperature control at the “...” or MAX position.
2. When the indicator light goes out, turn the steam control to the suitable position.

Burst of steam:

Set the temperature control at the “...” or MAX position, then press down the burst of steam button.

Dry ironing:

Turn the steam control to minimum position, then set the temperature control to the suitable position.

Self cleaning:

Fill with water, then plug the iron into the mains, Set the temperature control to the maximum position. About 3 minute later, press the self clean button for about 1 minute. Steam and hot water will be sprayed to clean the steam chamber. For best results use this function once every two weeks.

Anti-drip:

This iron is equipped with a drip stop function: the iron automatically stops steaming when the temperature is too low to prevent water from dripping out of the soleplate.

Anti-calc:

The Anti-calc function filtrate the minerals from the water to prevent mineral residue build up at the steam chamber.

1. Before filling water, please pull out the plug first.
2. Set the steam control to the minimum position.
3. Pull down the cover of water filling mouth, then fill water.

1 Year Warranty

Imported By R Weatherdon & Co Pty Ltd

Sydney - Australia

www.weatherdon.com.au

Made in China

Automatic shut off:

If the iron is switched on and not moved for a period of 8 minutes while standing on its heel, or 30 seconds while standing on the soleplate, an internal safety feature will switch the iron off and the auto shut off indicator will blink. Move the appliance sharply to switch it on again.